
NEPA OUT

INSTALLATION INSTRUCTIONS FOR LUMINAIRE NEPA OUT



USER INSTRUCTIONS

- •The installation of the unit must be done by a qualified electrician.
- •The unit must be earthed in case an earth connecting point exists.
- •Ensure that the mains is switched off during servicing.
- •Do not use bulb(s) bigger than the indicated on units name-plate or packaging.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- •Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- •The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.



www.bright.gr

Factory: 5 Kefalovrisou Str., Monomati, Axarnai, P.O. Box 13677, Athens, Greece Tel: (+30) 210 6208 230 Fax: (+30) 210 62 08 262



