

STATUS 1F SSLED

⊖ indoor/ downlight recessed spots



1

a Cut the hole on ceiling

170

157 x 157

~220 -240V driver

b Make wiring connections

tool accessories

2 Place the luminaire in the ceiling hole. Firstly, adjust the one side

3 Secure using retaining screws. Hold the luminaire while using the drill.

x2

4 Grouting. Paint the false ceiling

Paint

USER INSTRUCTIONS

- The installation of the unit must be done by a qualified electrician.
- The unit must be earthed in case an earth connecting point exists.
- Ensure that the mains is switched off during servicing.
- Do not use bulb(s) bigger than the indicated on units name-plate or packaging.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.
- LED modules are replaced only by the manufacturer.

CAUTION
Replace any cracked shield



CAUTION
Wear anti-static gloves before you touch LED systems

