

# STATUS 2F SSLED

⊖ indoor/downlight recessed spots



**1 Installation**

a. Cut the hole on ceiling  
b. Pass cable through the fixture

**2**

Fit luminaire on false ceiling. Fit first the one side

**3** Secure the fitting on ceiling with screws. Provide enough resistance with your hand.

**4**

After installing the fitting you need filling material to fill the gaps on ceiling. Then paint the ceiling.

**5** Make wiring connections.

driver x2  
~220 -240V

**6**

Screw the frame into the fixture

**USER INSTRUCTIONS**

- The installation of the unit must be done by a qualified electrician.
- The unit must be earthed in case an earth connecting point exists.
- Ensure that the mains is switched off during servicing.
- Do not use bulb(s) bigger than the indicated on units name-plate or packaging.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.
- LED modules are replaced only by the manufacturer.

**CAUTION**

Wear anti-static gloves before you touch LED systems



**CAUTION**

Replace any cracked shield



**Factory**

5 Kefalovrisou Str., Monomati, Acharnai, P.O. Box 13677, Athens, Greece | Tel: (+30) 210 6208 230  
E-mail: info@bright.gr | www.bright.gr

