






FUGA 2 RING SP


INSTALLATION INSTRUCTIONS FOR LUMINAIRE FUGA 2 RING SP




1 Suspension installation system hole patterns




2 CEILING




3 Adjust (4) stand extensions



4 Installation



5 Pass the suspension cable through the stand extension



USER INSTRUCTIONS

- The installation of the unit must be done by a qualified electrician.
- The unit must be earthed in case an earth connecting point exists.
- Ensure that the mains is switched off during servicing.
- Do not use bulb(s) bigger than the indicated on units name-plate or packaging.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.
- LED modules are replaced only by the manufacturer.



Last updated: March 2016