

NOTUS 8 LINEAR LED

APR 2019

installation instructions

indoor lighting / profiles



1

Cut hole on ceiling
Remove the cover

2

Remove heatsink
to access profile
and drivers

3

Make wiring connections

Please notice the
screw washer
between the modules.

LINEAR LED profile
is secured on
the fixture with
a safety wire.

CAUTION
Wear anti-static gloves
before you touch LED systems

4

5

Rotate the metal
strip to secure fixture
on the ceiling.
Attach the heatsink
and the cover.

USER INSTRUCTIONS

- The installation of the unit must be done by a qualified electrician.
- The unit must be earthed in case an earth connecting point exists.
- Ensure that the mains is switched off during servicing.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.
- LED modules are replaced only by the manufacturer.

CAUTION
Replace any cracked shield



BR//GHT
SPECIAL LIGHTING

Factory

5 Kefalovrisou Str., Monomati, Acharnai, P.O. Box 13677, Athens, Greece
Tel: (+30) 210 6208 230 | E-mail: info@bright.gr | www.bright.gr

IP40



GREENLIGHT