


# TERES M5 04 SQUARE SH E27

INSTALLATION INSTRUCTIONS FOR LUMINAIRE TERES M5 04 SQUARE SH E27



## USER INSTRUCTIONS

- The installation of the unit must be done by a qualified electrician.
- The unit must be earthed in case an earth connecting point exists.
- Ensure that the mains is switched off during servicing.
- Do not use bulb(s) bigger than the indicated on units name-plate or packaging.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.

IP65  

Date Issued: June 2014

**BRIGHT**  
SPECIAL LIGHTING

www.bright.gr

Factory: 5 Kefalovrisou Str., Monomati, Axarnai, P.O. Box 13677, Athens, Greece  
Tel: (+30) 210 6208 230 Fax: (+30) 210 62 08 262



GREENLIGHT