

NUDO

INSTALLATION INSTRUCTIONS FOR LUMINAIRE NUDO

1 In construction phase
Build the box in the wall

cap

junction box

2 Cover box with cap to keep it clean.

The hole in the middle enables the removal of the cap.

3 Installation
1. Release the (4) screws with screw driver

2. Place/replace lamp

allen wrench No. 4

4 1. Insert fitting in the box and secure with screws (4).
2. Make **wiring connections**.

x4

5 Fit the end cap on the fitting and tighten the (4) screws.

USER INSTRUCTIONS

- The installation of the unit must be done by a qualified electrician.
- The unit must be earthed in case an earth connecting point exists.
- Ensure that the main supply is switched off during servicing.
- Do not use bulb(s) bigger than the indicated on units name-plate or packaging.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.

IP65  

Date Issued: May 2014/1

BR//GHT
SPECIAL LIGHTING

www.bright.gr

Factory: 5 Kefalovrisou Str., Monomati, Axarnai, P.O. Box 13677, Athens, Greece
Tel: (+30) 210 6208 230 Fax: (+30) 210 62 08 262

