



# NEXUS DAMA


INSTALLATION INSTRUCTIONS FOR LUMINAIRE NEXUS DAMA




**1 Installation**  
1. Release the (4) screws with screw driver



**2 Place/replace lamp**




**3 In construction phase**  
Build the box in the wall



junction box


cap

**4 Cover box with cap to keep it clean.**




The hole in the middle enables the removal of the cap.


**5**  
1. Insert fitting in the box and secure it with screws  
2. Make wiring connections



**6 Close caps and tighten the screws**



Allen screws



allen wrench No. 3

## USER INSTRUCTIONS

- The installation of the unit must be done by a qualified electrician.
- The unit must be earthed in case an earth connecting point exists.
- Ensure that the main supply is switched off during servicing.
- Do not use bulb(s) bigger than the indicated on units name-plate or packaging.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.

IP65  

Date Issued: May 2014/1

**BR//GHT**  
SPECIAL LIGHTING

www.bright.gr

Factory: 5 Kefalovrisou Str., Monomati, Axarnai, P.O. Box 13677, Athens, Greece  
Tel: (+30) 210 6208 230 Fax: (+30) 210 62 08 262

